



Providing CO₂ lasers and CO₂ laser Tubes for industrial applications

Home » Products » CL Series CO₂ Laser Tube


CL Series CO₂ Laser Tube (Laser Consumable for Laser Marking Machine, Laser Cutting Machine & Laser Engraving Machine)

Country of Origin: China
Product Standard: Q/EFR/J 1.1-2012
Certifications: CE certificate, Chinese technical letters patent

Performance and Application

Our standard CL series CO₂ laser tube is a common laser equipment accessory that is characterized by a stable performance, reliable quality and low failure rate.


The CO₂ laser tube is applicable for laser cutting, laser engraving, and laser marking in different industries, including advertising, packaging, craftwork processing, decorative construction materials, and clothing.



Parameters

Model	Length(mm)	Outer Diameter(mm)	Outer Power(w)	Maximum Power(w)	Operating Current	Catalyst
700CL	700±20	φ 50±2	35	40	20	No
800CL	800±20	φ 50±2	40	50	20	No
1000CL	1000±20	φ 50±2	50	60	20	No
1200CL	1200±20	φ 55±2	60	70	22	Yes
1600CL	1600±20	φ 60±2	80	95	25	Yes

Product Showcase



Features

- 1. Stable Laser Power:** We use special equipment and US imported gas to allow this laser consumable to have a stable laser power, effectively slowing down the dissociation rate of working gas, and prolonging the service life.
- 2. Good Beam Mode:** The CO₂ laser tube can achieve a TEM00 mode above 95%, and features a laser spot size ranging from 3-5mm.
- 3. High Power:** The laser power is generally above 70W, and the power of the 1,600mm CL series CO₂ laser tube can exceed 100W.

Operating Current

Model	Input Current (mA)	Max. Operating Current (mA)	Max Current in Long-term Operation	Service Life	Matched EFR Power Supply	Starting Voltage
700CL	20mA	20mA and below	20mA and below	3000 hours(operation current ≤20mA)	PS-T60	14KV
800CL	20mA	20mA and below	20mA and below	3000 hours(operation current ≤20mA)	PS-T60	14KV
1000CL	20mA	20mA and below	20mA and below	3000 hours(operation current ≤20mA)	PS-T60	16KV
1200CL	22mA	22mA and below	22mA and below	3000 hours(operation current ≤20mA)	PS-60,PS-ES80,PS-	19KV

1600CL	25mA	25mA and below	23mA and below	≤22mA)	F80	28KV
				3000 hours(operation current ≤23mA)	PS-80,PS-ES80,PS-F80	

1600 CL Series CO₂ Laser Tube

The 1600 CL series CO₂ laser tube has an excellent engraving performance and can achieve a high frequency pulse engraving under the 6mA current. The laser tube is matched with a PS-N80 EFR power supply, and has a high voltage on the positive pole, with a starting voltage at 28KV.

Operating Condition

1) Water cooling

Coolant: pure water

Flow rate: 3-5L/min.

Standard water temperature: 10°C -40°C

2) Working environment

Temperature: 2°C-40°C

Humidity: 10%-60%

3) Operating current

The CO₂ laser tube requires an input current of 25mA, a maximum operating current of 25mA and a current of 23mA and below for long-term operation. If the operating current is kept at 23mA or below, the service life is up to 3,000 hours. These currents should be based on the currents displayed on the ammeter, which is in a series connection with the cathode.

1200 CL Series CO₂ Laser Tube

With excellent capabilities to cut and engrave, the 1200 series CO₂ laser tube can be used as a laser cutting machine accessory and a laser engraving machine accessory. It can achieve a high frequency pulse engraving under a 5mA current. The laser tube is matched with a PS-N80 EFR power supply and has a high voltage on the positive pole, with the starting voltage at 19KV.

Operating Condition

1) Water cooling

Coolant: pure water

Flow rate: 2-5L/min.

Standard water temperature: 10°C -40°C

2) Working environment

Temperature: 2°C-40°C

Humidity: 10%-60%

3) Operating current

The input current of the CO₂ laser tube is 22mA, as is the maximum current, and the long-term operation current is 22mA or below. The service life can be up to 3,000 hours if the current is kept at 22mA and below.

The above currents should be in accordance with the actual currents displayed on the ammeter, which is in a series connection with the cathode. If the laser tubes are used incorrectly for long-term, over-current use, the color of the negative electrode will change, and the service life significantly reduced.

Cleaning Tips: Please do not use cotton swabs or other wipes to scrub the windows on this laser equipment spare part. Doing so affects the output power.

The specified cleaning method for the windows is as follows

1. When the lens is stained, turn off the laser tube.
2. Use an air dust blower to blow away dust and dirt on the lens.
3. Use a syringe to spray ethanol on the lens.
4. After the ethanol evaporates, turn the laser tube back on.
5. If the above methods do not work effectively, professionals are required, who will use a cotton swab dipped in ethanol to clean the lens in a rotating fashion away from the center, outwards to the edge.

The best method is to protect the windows from contamination.

Special Notice


1. Do not use acetone to clean the glass.
2. When testing the light spot on organic glass, please keep the organic glass 300mm away from the windows.

Safety: As the CO₂ glass laser device generates invisible light, please wear eye protection gear when operating. A safety sign for high voltage is marked on the positive pole.

Storage and Transportation Requirements: When storing and transporting the CO₂ laser tube, please drain the cooling liquid and cover the tube ends with dustproof plastic bags. For storage, the required environmental temperature is 2-40°C and the humidity ranges from 10-60%.

Adhesive tapes and sponges should be used to fix the laser tubes and prevent sliding during transport. A 70mm sponge should be use at the end of the windows, and a 50mm sponge should be at the end of the fully reflecting mirror.

Package Size






[ZS Series CO₂ Laser Tube](#)



[F Series CO₂ Laser Tube](#)



[CL Series CO₂ Laser Tube](#)



[CO₂ Laser Power Supply](#)

[Home](#)

[About Us](#)

[Products](#)

[Photo Gallery](#)

[Application](#)

[Support](#)

[Video](#)

[Contact Us](#)

[ETW CLOUD](#)

[VRC](#)

[RSS](#)

[SITEMAP](#)

[LEGAL](#)

Supported by ETW International Inc. USA

Model of [Laser Tube: 1200CL](#)

Quantity of Laser Tube	1	1	2	4	6	8	10
Product Net Weight (Kg)	1.7kg	1.7kg	3.4kg	6.8kg	10.2kg	13.6kg	17kg
Carton Capacity	1 laser tube, small carton	1 laser tube, large carton	2 laser tubes	4 laser tubes	6 laser tubes	4 laser tubes +4 laser tubes	4 laser tubes
Carton Dimension (L×W×H)	131×16.5×12.5	141×25×21	141×42×21	141×42×34	141×42×47.5	/	/
Carton Dimension (with Sponge) (L×W×H)	131×24.5×20.5	141×33×29	141×50×29	141×50×42	141×50×55.5	/	/
Product Rough Weight (Kg)	2.5kg	4kg	7kg	12.6kg	17.9kg	24kg	29.5kg

Model of [Laser Tube: 1600CL](#)

Quantity of Laser Tube	1	1	2	4	6	8	10
Product Net Weight (Kg)	2.45kg	2.45kg	4.9kg	9.8kg	14.7kg	19.6kg	24.5kg
Carton Capacity	1 laser tube, small carton	1 laser tube, large carton	2 laser tubes	4 laser tubes	6 laser tubes	4 laser tubes +4 laser tubes	4 laser tubes
Carton Dimension (L×W×H)	168×16×12	179×25×21	179×42×21	179×42×34	179×42×48	/	/
Carton Dimension (with Sponge) (L×W×H)	168×24×20	179×33×29	179×50×29	179×50×42	179×50×56	/	/
Product Rough Weight (Kg)	4.0kg	5.75kg	10.3kg	14.95kg	21kg	29kg	35kg

Note

1. Carton dimension error: ±1cm
2. Rough weight error: ±1 kg

Quality Guarantee

Warranty: 360 days

1. Within 180 days from ex-factory date on the label, we replace free of charge if the power is less than 80% of rated power while the users operate according to our manual. The replaced laser tube will have same warranty as new ones. The single transportation freight will be afforded by buyer. When the laser tube structure is damaged or changed, we will not be responsible.
2. From 181st days to the 360th days from ex-factory date on the label, we repair or replace free of charge if the power is less than 75% of rated power while the users operate according to our manual. The replaced or repaired laser tube will have same warranty as the one which buyer purchased first time from us. The single transportation freight will be afforded by buyer. When the laser tube structure is damaged or changed, we will not be responsible.
3. We are not responsible for damage or problems that occur during the incorrect usage and do not fall in line with the instruction books.

Inquiry Form	
	<p>*Email</p> <input type="text" value="Your Email"/>
	<p>*Content</p> <div style="border: 1px solid black; height: 60px; width: 100%;"></div>
	<p>Product Name</p> <input type="text" value="http://efrlaser.com:8080/4-co2-laser-tube/200481"/>
	<p>Your Name</p> <input type="text" value="Your Full Name."/>
	<p>Company</p> <input type="text" value="Your Company Name."/>
	<p>Tel./Fax.</p> <input type="text"/>

Other products